

Proper Sizing for Insulating Rubber Gloves



Measure the circumference of the palm, as shown above and add 1" to the measurement to determine the glove size needed.

Example:

- A measurement of 9" plus the 1" would be 10" and would require a size 10 glove.

Glove Sizes Available: 8, 9, 10, 11 and 12

Please call us at Cementex Products, Inc. if you have any questions or would like to check stock.

Cementex

The Safety Tool Specialists

IF YOU NEED ANY HELP IN DETERMINING WHAT SIZE YOU NEED
CONTACT NATIONAL FUSE PRODUCTS, LICENSED DISTRIBUTORS FOR CEMENTEX
AT 1-800-328-0496 OR EMAIL SALES@NATIONALFUSE.COM